# HI99300 • HI99301

Waterproof EC, TDS and Temperature Meter with Advanced Features



# INSTRUCTION MANUAL



# Dear

Thank you for choosing a Hanna Instruments product.

Customer, | Please read this instruction manual carefully before using these meters.

> This manual will provide you with the necessary information for correct use of these meters, as well as a precise idea of their versatility.

> If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com or view our worldwide contact list at www.hannainst.com.

All rights are reserved. Reproduction in whole or in part is prohibited without the written consent of the copyright owner, Hanna Instruments Inc., Woonsocket, Rhode Island, 02895, USA.

# TABLE OF CONTENTS

Table of Contents	. ქ
Preliminary Examination	4
General Description and Intended Use	5
Main Features	6
Specifications	7
Display Description	. 8
Operational Guide	9
Meter Setup	13
Battery Replacement	14
Accessories	. 15
Probe Maintenance	17
Certification	18
Recommendations for Users	19
Warranty	
•	

Remove the meter from the packing material and examine it to make sure that no damage has occurred during shipping. If there is any damage, contact your local Hanna Instruments Office.

Each meter is supplied complete with:

- H1763063 pH/EC/TDS probe with built-in temperature sensor, DIN connector and 1m (3.3') cable
- HI70031 1413  $\mu$ S/cm and HI70032 1382 ppm 1 sachet each for HI99300
- HI70030 12880  $\mu$ S/cm and HI70038 6.44 ppt 1 sachet each for HI99301
- 100 mL beaker (1 pcs.)
- Alkaline batteries: 1.5V AAA (3 pcs.)
- Rugged carrying case
- Calibration certificate of meter
- Calibration certificate of probe
- Instruction manual

Note: Save all packing material until you are sure that the meter functions correctly. All defective items must be returned in the original packing with the supplied accessories. H199300 and H199301 are conductivity, total dissolved solids and temperature measurement encountered in manufacturing and environmental testing protocols.


To increase precision, two models are available, with different conductivity ranges, for applications from purified to brackish waters.

All operations, settings and temperature scale selections, are made through only 2 buttons.

The housing is waterproof and rated for IP67 conditions. The supplied multi-parameter probe, HI763063, includes EC/TDS and temperature in one convenient, rugged probe. Other user selectable features include different TDS factors from 0.45 to 1.00, and a range of temperature coefficients (β) from 0.0 to 2.4% for better solution temperature compensation.

### Main features:


- Simultaneous EC/TDS and temperature measurements on a large LCD display;
- Selectable temperature unit.
- HI763063 dedicated EC/TDS/temperature probe
- Probe quick connect system
- Battery life indication and low battery detection
- Auto-off function
- Keystroke confirmation tone
- Waterproof casing IP67



Range   EC			HI99300	HI99301	
Range   TDS   O to 2000 ppm   0.00 to 10.00 ppt		EC.	0 to 3999 $\mu$ S/	0.00 to 20.00 mS/	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Range	LC			
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		TDS	0 to 2000 ppm	0.00 to 10.00 ppt	
Kesolution       TDS       1 ppm (mg/L)       0.01 ppt (g/L)         Temp.       0.1 °C / 0.1 °F         Accuracy       ± 2% F.S. (EC/TDS)         ② 20°C/68°F       ± 0.5 °C / ± 1.0 °F Temperature         Temperature       Automatic, with β selectable from 0.0 to 2.4 %/ °C with 0.1 increments         Automatic, one-point at 1413 μS/cm 12.88 mS/cm         EC/TDS       or 1382 ppm or 6.44 ppt (CONV=0.5) (CONV=0.5) or 1500 ppm or 9.02 ppt (CONV=0.7)         TDS conversion factor       Selectable from 0.45 to 1.00 with 0.01 increments         H1763063 EC/TDS/temperature       Selectable from 0.45 to 1.00 with 0.01 increments         Battery type / life       1.5V AAA (3 pcs.) approx. 500 hours of continuous use         Auto-Off       user selectable: after 8 min, 60 min or disabled         Environment       0 to 50 °C (32 to 122 °F) RH max. 100%		Temp.	-5.0 to 105.0 °C	/ 23.0 to 221.0 °F	
tion IDS   1 ppm (mg/L)   0.01 ppt (g/L)   Temp.		EC	1 <i>µ</i> S∕cm	0.01 mS/cm	
Accuracy  20°C/68°F  Temperature Compensation  Automatic, with β selectable from 0.0 to 2.4 %/ °C with 0.1 increments  Automatic, one-point at 1413 μS/cm 12.88 mS/cm  EC/TDS  ar 1382 ppm or 6.44 ppt (CONV=0.5) (CONV=0.5)  or 1500 ppm or 9.02 ppt (CONV=0.7) (CONV=0.7)  TDS conversion factor  Frobe (included)  Battery type / life Auto-Off  Environment  Automatic, one-point at 1413 μS/cm 12.88 mS/cm  1.413 μS/cm 12.88 mS/cm  1.44 ppt (CONV=0.5) (CONV=0.5)  or 1500 ppm or 9.02 ppt (CONV=0.7) (CONV=0.7)  TDS conversion factor  Increments  HI763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  1.5V AAA (3 pcs.) approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment  O to 50 °C (32 to 122 °F) RH max. 100%		TDS			
		Temp.		<u> </u>	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Accuracy				
Compensation  O.0 to 2.4 %/ °C with 0.1 increments  Automatic, one-point at  1413 µS/cm 12.88 mS/cm  EC/TDS  or 1382 ppm or 6.44 ppt  (CONV=0.5) (CONV=0.5)  or 1500 ppm or 9.02 ppt  (CONV=0.7) (CONV=0.7)  TDS conversion factor  Frobe (included)  Selectable from 0.45 to 1.00 with 0.01 increments  H1763063 EC/TDS/temperature  sensor, DIN connector and 1 m (3.3')  cable  Battery type / life Auto-Off  user selectable: after 8 min, 60 min or disabled  Environment  O to 50 °C (32 to 122 °F) RH max.  100%	@ 20°C/68°F				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	Temperature				
EC/TDS or 1382 ppm or 6.44 ppt  (CONV=0.5) (CONV=0.5) or 1500 ppm or 9.02 ppt (CONV=0.7) (CONV=0.7)  TDS conversion factor  Probe (included) Selectable from 0.45 to 1.00 with 0.01 increments  H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life 1.5V AAA (3 pcs.) approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%	Compensa	tion	0.0 to 2.4 %/ °C with 0.1 increments		
EC/TDS or 1382 ppm or 6.44 ppt (CONV=0.5) (CONV=0.5) or 1500 ppm or 9.02 ppt (CONV=0.7)  TDS conversion factor Selectable from 0.45 to 1.00 with 0.01 increments H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life 1.5V AAA (3 pcs.) approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%	-				
Calibration  (CONV=0.5) (CONV=0.5) or 1500 ppm or 9.02 ppt (CONV=0.7) (CONV=0.7)  TDS conversion factor  H1763063 EC/TDS/temperature Probe (included)  Battery type / life Auto-Off  Environment  (CONV=0.5) Or 1500 ppm or 9.02 ppt (CONV=0.7)  Selectable from 0.45 to 1.00 with 0.01 increments H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable 1.5V AAA (3 pcs.) approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment  O to 50 °C (32 to 122 °F) RH max. 100%				12.88 mS/cm	
or 1500 ppm or 9.02 ppt (CONV=0.7) (CONV=0.7)  TDS conversion factor Selectable from 0.45 to 1.00 with 0.01 increments  H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%	EC/TDS				
(CONV=0.7) (CONV=0.7)  TDS conversion Selectable from 0.45 to 1.00 with 0.01 increments  HI763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life User Selectable: after 8 min, 60 min or disabled  Environment O to 50 °C (32 to 122 °F) RH max. 100%	Calibration				
TDS conversion factor  Selectable from 0.45 to 1.00 with 0.01 increments  H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment  O to 50 °C (32 to 122 °F) RH max. 100%					
factor increments  H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  Battery type / life Auto-Off user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%					
Probe (included)  H1763063 EC/TDS/temperature sensor, DIN connector and 1 m (3.3') cable  1.5V AAA (3 pcs.) approx. 500 hours of continuous use  user selectable: after 8 min, 60 min or disabled  Environment  0 to 50 °C (32 to 122 °F) RH max. 100%	TDS conversion		Selectable from 0.45 to 1.00 with 0.01		
Probe (included) sensor, DIN connector and 1 m (3.3') cable  Battery type / life approx. 500 hours of continuous use  Auto-Off user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%	factor		increments		
cable  Battery type / life approx. 500 hours of continuous use  Auto-Off user selectable: after 8 min, 60 min or disabled  Environment 0 to 50 °C (32 to 122 °F) RH max. 100%	Probe (included)		HI763063 EC/TDS/temperature		
Battery type / life   1.5V AAA (3 pcs.)   approx. 500 hours of continuous use    Auto-Off   user selectable: after 8 min, 60 min or disabled    Environment   0 to 50 °C (32 to 122 °F) RH max. 100%			sensor, DIN connector and 1 m (3.3')		
Auto-Off  approx. 500 hours of continuous use user selectable: after 8 min, 60 min or disabled  Environment  0 to 50 °C (32 to 122 °F) RH max. 100%			cable		
Auto-Off    Solution   Continuous use	Rattory by	oo / lifo	1.5V AAA (3 pcs.)		
disabled   Continuous	Durrery type / life		approx. 500 hours of continuous use		
Environment disabled 0 to 50 °C (32 to 122 °F) RH max. 100%	Auto Off	user selectable: after 8 min, 60 min or			
100%	AUIU-UII		·		
100%	Environment	0 to 50 °C (32 to 122 °F) RH max.			
Mater Dimensions 154 /2 20 mm // 1 2 5 1 2"	LIIVIIOIIIIIEIII		100%		
Meter Diffiensions   154 x 63 x 30 mm (6.1 x 2.5 x 1.2 )	Meter Dimensions		154 x 63 x 30 mm (6.1 x 2.5 x 1.2")		
Meter Mass					
(with batteries) 196 g (6.91 oz.)	(with batte				
Casing Ingress IPA7	Casing Ingress Protection Rating		IP67		
Protection Rating   " O			II U/		

displays  $\mu {\rm S}$  for  $\mu {\rm S/cm}$ . displays mS for mS/cm.

- 1 Automatic Temperature Compensation indicator
- 2 Stability indicator
- 3 Battery percentage
- 4 TDS conversion factor
- 5 Low battery indicator
- 6 Measurement unit
- 7 Primary LCD
- 8 Temperature unit
- 9 Secondary LCD
- 10 Meter modes indicator
- 11 EC calibration tag



Each meter is supplied with batteries. Before using the meter for the first time, open the battery compartment and insert batteries, observing the polarity (see "Battery Replacement").

### TO CONNECT THE ELECTRODE


With the meter turned off, connect the H1763063 probe to the DIN socket on the bottom of the meter by aligning the pins and pushing in the plug firmly. Remove the protective cap from the probe before taking any measurements.

### TO TURN THE METER ON

To turn the meter ON, press the 😃 button on the front of the meter. If it does not turn on, make sure that the batteries are properly installed in their place.

The meter is provided with an active acoustic signal when a key is pressed.

At start-up the meter displays all LCD segments for a few seconds, followed by the percentage indication of the remaining battery life, displaying "WAIT" until electrode check is in process then the meter enters the normal measurement mode.



Note: The meter detects the presence and the type of the probe at its input.


- If the probe is not connected the message "NO" "PROBE" appears alternatively on the secondary LCD.
- If the probe is not compatible "WRONG" "PROBE" message appears alternatively on the secondary LCD line with "---" blinking on the first LCD line.
- If the readings are out of range, the nearest range limits are displayed blinking (E.g. 3999  $\mu$ S -5.0 °C).

### TO SELECT THE MEASUREMENT RANGE

While in measurement mode, press the **SET** button to select EC or TDS measurement on the LCD.

### TO FREEZE THE MEASUREMENT VALUES

While in measurement mode, press and hold the **SET** button until "**HOLD**" appears on the second LCD line for 1 second. The reading of EC and temperature will be frozen on the LCD with "H" blinking.



Press any button to resume active measurements.

### TO FNTER CALIBRATION MODE

Press and hold the button until "POWER" and Figure 1 tag is replaced by "STD", Figure 1 tag if standard calibration is selected from setup menu. Release the button.

### TO ENTER SETUP MODE

Press and hold button until "STD" and Lag is replaced by "SETUP" and Lag. Release the button.

### TO TURN THE METER OFF

While in measurement mode, press the **button**."**POWER**" and **off** tag will appear. Release the button.

### EC MEASUREMENT AND CALIBRATION

Placethe probe in the sample to be tested. Use plastic beakers or containers to minimize any electromagnetic interference. Tap the probe lightly on the bottom of the container to remove



air bubbles that may be trapped inside the tip. Wait for a few minutes for the temperature sensor to reach thermal equilibrium, when the  $\boxtimes$  tag disappears. The LCD displays the EC or TDS value (automatically compensated for temperature) on the primary LCD, while the secondary LCD displays the sample temperature.

### EC calibration

Before calibration, rinse the sensor tip with a heavy stream of purified water then shake excess water from the probe.



Select calibration "STD" CAL. The meter enters the calibration mode and " $\mu$ S 1.41 USE" (H199300) or "mS 12.88 USE" (H199301) is displayed with CAL tag blinking. Immerse the probe in calibration solution. If the standard value is recognized "REC" is displayed then "WAIT" until the calibration is accepted. The LCD will display "SAVE" for 1 second and return to normal measurement mode. If the standard is not recognized or the slope is out of accepted range "--- WRONG" is display. Change the calibration solution, clean the electrode or press any key to exit calibration. When the calibration procedure is completed, the "CAL" tag is turned on.

Note: - Beta should be set to 1.9 during calibration.

- Since there is a known relationship between the EC and TDS reading, it is not necessary to calibrate the meter in TDS. If the conversion factor is either 0.5 or 0.7, the meter will allow a direct calibration in TDS by using the Hanna calibration solutions.

### **SETUP MODE**

Setup mode allows the selection of the Temperature unit. Auto-off, Beep, temperature compensation factor for EC and TDS conversion factor. To enter Setup mode press and hold button until "STD" and Lag is replaced by "SETUP" and MODE tag. Release the button.

• "TEMP" is displayed on the secondary LCD line with the current temperature unit (E.g. "TEMP °C"), for °C/°F selection, use the SET button. After the temperature unit has been selected, press to confirm and to enter the "A-OFF" selection.



• Use the **SET** button, to cycle through the auto-off choices: 8 minutes ("8", default value), 60 minutes ("60") or disabled ("---"). Press @ to confirm and to enter the "**BFFP**" selection



• To switch ON or OFF the beep tone, press the SET button; press 😃 to confirm and to enter the calibration buffer selection "BETA".

• "BETA" is displayed on the secondary LCD line with the current temperature compensation factor (E.g. "1.9"), use **SET** button to modify the value. Press to confirm and to enter TDS conversion factor "CONV"



• "CONV" is displayed on the secondary LCD line with the current TDS factor (E.g. "0.50"), for selecting other value use the **SET** button. Press 😃 to confirm and to return to normal mode.



### BATTERY REPLACEMENT


When the remaining battery life is less than 10% the battery tag blinks on the display to warn the user.



### Battery Error Prevention System (BEPS)

If the battery is too weak ("0%") the display shows "bAtt", "DEAD" for few seconds then the meter power off. Immediately replace the batteries with new ones.

The batteries are accessed by opening the battery cover on the back of the instrument. Remove protective boot if present.



Replace the three 1.5V AAA alkaline batteries located in the battery compartment, observing the indicated polarity.



Replace the battery cover making sure that the gasket is in place.

HI763063	Conductivity probe/total dissolved solids with built-in temperature sensor, DIN connector and 1 m (3.3') cable	
HI7030M	12880 $\mu$ S/cm solution, 230 mL bottle	
HI7031M	1413 $\mu$ S/cm solution, 230 mL bottle	
HI7032M	1382 ppm (mg/L) solution, 230 mL bottle	
HI70038M	6.44 ppt (g/L) solution, 230 mL	
HI70442M	1500 ppm (mg/L) solution, 230 mL	
HI710028	Silicon rubber boot orange color	
HI76405	Electrode holder	



### **PREPARATION**

• Remove the protective cap. Rinse with water.

### STORAGE

• Replace the protective cap.

Note: NEVER STORE THE ELECTRODE IN DISTILLED WATER.

### CLEANING PROCEDURE

- Soak in Hanna HI7061 general cleaning solution or for approximately 20 minutes. Rinse well and calibrate before using.
- The two pins can be cleaned by rubbing with abrasive paper.

All Hanna Instruments conform to the **CE European Directives**.



RoHS compliant

**Disposal of Electrical & Electronic Equipment.** The product should not be treated as household waste. Instead hand it over to the appropriate collection point for the recycling of electrical and electronic equipment which will conserve natural resources.

**Disposal of waste batteries.** This product contains batteries, do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling.

Ensuring proper product and battery disposal prevents potential negative consequences for the environment and human health. For more information, contact your city, your local household waste disposal service, the place of purchase or go to www.hannainst.com.



# Recommendations for Users

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any variation introduced by the user to the supplied equipment may degrade the meters' performance. For yours and the meter's safety do not use or store the meter in hazardous environments.

### Warranty

H199300 and H199301 are warranted for two years against defects in workmanship and materials when used for their intended purpose and maintained according to instructions. This warranty is limited to repair or replacement free of charge. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered.

If service is required, contact your local Hanna Instruments Office. If under warranty, report the model number, date of purchase, serial number (see engraved in the back of the meter) and the nature of the problem. If the repair is not covered by the warranty, you will be notified of the charges incurred. If the meter is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization number from the Technical Service department and then send it with shipping costs prepaid. When shipping any meter, make sure it is properly packed for complete protection.

Hanna Instruments reserves the right to modify the design, construction or appearance of its products without advance notice.

## World Headquarters

Hanna Instruments Inc. Highland Industrial Park 584 Park East Drive Woonsocket, RI 02895 USA www.hannainst.com

### **Local Office**

Hanna Instruments Inc. 270 George Washington Highway Smithfield, RI 02917

Phone: 800.426.6287 Fax: 401.765.7575

e-mail: tech@hannainst.com

