



HI9147 Dissolved Oxygen Meter for Aquaculture

- Automatic Temperature Compensation (ATC)
- Waterproof
- Backlit LCD

The HI9147 is designed for aquaculture applications. This unit is unique among our family of DO meters as it is supplied with a galvanic probe.

Unlike polarographic probes, galvanic DO probes require no conditioning time. When you need to measure multiple samples in a given period of time, simply turn the meter on and start taking measurements.

The HI9147 is a must have for DO sensitive organisms or high bio-load environments.

DO Levels at 100% Saturation

Temperature	Salinity (ppt)				
	0	10	20	30	40
10°C / 50°F	13.0	12.2	11.4	10.6	9.8
15°C / 59°F	10.3	9.7	9.2	8.6	8.1
20°C / 68°F	9.4	8.8	8.4	7.9	7.4
25°C / 77°F	8.5	8.0	7.6	7.2	6.7
30°C / 86°F	7.8	7.4	7.0	6.6	6.2

Specifications	HI9147
DO	Range 0.0 to 50.0 mg/L (ppm); 0 to 600% saturation
	Resolution 0.1 mg/L (ppm); 1% saturation
	Accuracy (@ 20°C/68°F) ±1% of reading
Temperature	Range 0.0 to 50.0°C; 32.0 to 122.0°F
	Resolution 0.1°C; 1°F
	Accuracy (@ 20°C/68°F) ±0.2°C; ±1°F (excluding probe error)
Additional Specifications	Calibration manual, in saturated air
	Temperature Compensation automatic, 0° to 50°C (32°F to 122°F)
	Altitude Compensation 0 to 4000 m (resolution 100 m)
	Salinity Compensation 0 to 51 g/L (ppt) (1 g/L resolution)
	Probe HI76409/4 galvanic DO probe (fixed) with internal temperature sensor, DIN connector and 4 m (13') cable (HI9147-04), 10 m (33') cable (HI9147-10), 15 m (49') cable (HI9147-15) or 20 m (66') cable (HI9147-20) (included)
	Battery Type / Life 1.5V AAA (3) / approx. 1000 hours of continuous use without backlight
	Environment 0 to 50°C (32 to 122°F); RH max 95% non-condensing
	Dimensions 185 x 72 x 36 mm (7.3 x 2.8 x 1.4")
	Weight 450 g (15.9 oz.)
Ordering Information	HI9147-04 is supplied with HI76409/4 probe with 4 m (13') cable and spare membranes (5), electrolyte solution (30 mL), batteries, screwdriver and instructions.
	HI9147-10 is supplied with HI76409/10 probe with 10 m (32.8') cable and spare membranes (5), electrolyte solution (30 mL), batteries, screwdriver and instructions.
	HI9147-15 is supplied with HI76409/15 probe with 15 m (49.2') cable and spare membranes (5), electrolyte solution (30 mL), batteries, screwdriver and instructions.
	HI9147-20 is supplied with HI76409/20 probe with 20 m (65.6') cable and spare membranes (5), electrolyte solution (30 mL), batteries, screwdriver and instructions.

DO solutions and accessories begin on page 7.21