

pH 5

○ pH - mV - T

MAIN FEATURES

IP67 watertight portable pH meter. Resolution 0,01 pH. Interchangeable electrode, temperature sensor and open partitions. **Wide 3-colour LCD display with indication of the buffers used for calibration and measurement stability.** Push-button calibration on 3 points with 5 values of USA buffers. mV reading for pH electrode diagnosis. **Temperature reading.** Auto power off function. **Automatic temperature compensation** (0...60 °C). Self-diagnosis messages: low batteries, calibration errors. Power supply with 2 x 1.5V AAA batteries included, compatible with rechargeable batteries too. 1 year warranty on electronic parts.

Measuring range: pH: -2,00...16,00 (Resolution 0,01 pH); mV: -1.000...+1.000 mV; °C: 0,0...60,0 (0,1 °C).

The KIT includes: 1 sachet x 25ml pH 7 and pH 4 buffer solution, 1 sachet of electrode storage solution, calibration cap, lanyard, tissue, quick manual and cardboard case.



Name	Description	p/n
pH 5 KIT	pH 5 Kit complete	50014063
pH 5 ECOPACK	pH 5, batteries 1,5 V AAA, lanyard and quick manual	50014053
pH 5 ONLY BODY	pH 5, without sensor	50014073
ELECTRODE pH	Replacement electrode for pH 5	50014403

pH 5 Food

○ pH - mV - T

MAIN FEATURES

IP67 watertight portable pH meter. Resolution 0,01 pH. Interchangeable polymer-tipped electrode, temperature sensor and open partitions for **measurements in the food industry.** **Wide 3-colour LCD display with indication of the buffers used for calibration and measurement stability.** Push-button calibration on 3 points with 5 values of USA buffers. mV reading for pH electrode diagnosis. **Temperature reading.** Auto power off function. **Automatic temperature compensation** (0...60 °C). Self-diagnosis messages: low batteries, calibration errors. Power supply with 2 x 1.5V AAA batteries included, compatible with rechargeable batteries too. 1 year warranty on electronic parts.

Measuring range: pH: -2,00...16,00 (Resolution 0,01 pH); mV: -1.000...+1.000 mV; °C: 0,0...60,0 (0,1 °C).

The KIT includes: 1 sachet x 25ml pH 7 and pH 4 buffer solution, 1 sachet of electrode storage solution, calibration cap, lanyard, tissue, quick manual and cardboard case



Name	Description	p/n
pH 5 Food KIT	pH 5 Food Kit complete	50014113
pH 5 Food ECOPACK	pH 5 Food with batteries 1,5 V AAA, lanyard, quick manual	50014123
ELECTRODE pH	Replacement electrode for pH 5 Food	50014423