

COND 5

○ Conductivity - TDS - Salinity - T

MAIN FEATURES

IP67 watertight portable conductivity meter for Conductivity, TDS and Salinity measurement. High-durable interchangeable electrode. **Wide 3-color LCD display** with indication of the buffers used for calibration and measurement stability. Push-button calibration on 3 points with 3 standard values, choosing between 84, 1413 μ S e 12,88 mS. Reading and automatic temperature compensation with TR= 20/25 °C and adjustable coefficient TC= 0,00...4,00%/°C. TDS Factor: 0,40...1,00. Self-diagnosis messages. Power supply with 2 x 1.5V AAA batteries included, compatible with rechargeable batteries too. Auto power off function. 1-year warranty on electronic parts.

Measuring range: COND 0,01 μ S...200 mS; TDS 0,01 ppm...199,9 ppt; Salinity 0,1mg/l...100,0 g/.

The KIT includes: 1 sachet x 25ml 1413 μ S and 12,88 mS buffer solution, calibration cap, lanyard, tissue, quick manual and cardboard case.



Name	Description	p/n
COND 5 KIT	COND 5 Kit complete	50014213
COND 5 ECOPACK	COND 5, batteries 1,5 V AAA, lanyard and quick manual	50014203
COND 5 ONLY BODY	COND 5, without sensor	50014223
SENSOR COND	Replacement sensor for COND 5	50014413
VPT SOIL COND 5	Conductivity cell with temperature probe, C = 1, fo ground measurement, working range 10 μ S ... 50 mS, cable 1.5 m for COND 5	50014713

ORP 5

○ Redox - T

MAIN FEATURES

IP67 watertight portable ORP/Redox meter. Resolution 0,1/1 mV. With microprocessor and interchangeable **high-durable electrode**. **ORP calibration** on one point defined by the user. Wide 3-color LCD display with indication of measurement stability. Auto power off function. **Temperature reading**. **Self-diagnosis messages**. Power supply with 2 x 1,5V AAA batteries included, compatible with rechargeable batteries too. 1 year warranty on electronic parts.

Measuring range: mV: -1.000...+1.000 mV; °C: 0,0...60,0 (0,1°C).

The KIT includes: : 1 bottle x 55ml Redox 475 mV solution, 1 sachet of electrode storage solution, calibration cap, lanyard, tissue, quick manual and carboard case.



Name	Description	p/n
ORP 5 KIT	ORP 5 Kit complete.	50014313
SENSOR REDOX	Replacement sensor for ORP 5	50014443

TESTER